



THE SMART CHOICE!



PureBeats Xtreme

HIFI SOUND EARBUDS

Model: PB-X10

USER MANUAL

Product specifications

Bluetooth version: V5.3

Transmission distance: 10M

Horn diameter: $\Phi 13\text{mm} \times 2$

Horn resistance: $32\Omega \pm 5\%$

Receiving sensitivity: -93dB

Frequency response range: 20Hz-20kHz

Battery capacity: 30mAh 3.7V

Music time: About 4-5 hours with a single headset (50% volume)

Water & Sweat Resistant: IPX5

Charging bay specification

Battery capacity: 320mAh 3.7V

Charging time: ≈ 1.5 hours

(All technical information is subject to actual performance)

Charge the charging box

Connect the charging case to the 5V power adapter with the Type-C charging cable

Warm tip: When the earbuds is put into the charging box, the blue light flashes three times to indicate that the battery in the charging box is low, please charge the charging box in time.



Indicators and voice prompts

Mode	Pilot lamp	Voice prompt
Power on	The blue light of the earbuds is on for 1 second	power_on
Power Off	The blue light of the earbuds is on for 1 second	power_off
Bluetooth connection successful	The primary and secondary earbuds lights are off	"connected"
Earbuds team up successfully	The primary earbuds blinks blue quickly, and the secondary earbuds is off	"pairing"
disconnection	The primary earbuds blinks blue quickly, and the secondary earbuds is off	"disconnected"
Earbuds battery low	The 500ms blue indicator blinks twice at short intervals for 12 seconds	"battery_low"
Charge your earbuds	Earbuds blue light constant, full off light	/
The charging case is low	Earbuds into the warehouse, warehouse low power (less than 3.5V), blue light flashes three times.	/
Box charging	The red light gradually breathes when the charging bin is charging	/
Charging case full	The red light is always on after the charging case is fully charged.	/

Product Operation Instructions

①Power on

Method 1: The earbuds automatically turn on when they are taken out of the box, and the earbuds is automatically powered on and paired.

Method 2: Left/right ear captain press the function key for 3 seconds to turn on.

②Shutdown

Method 1: Put the earbuds back into the charging case, and turn off the earbuds

Method 2: Automatically shut down after 3 minutes of disconnection from Bluetooth device.

Method 3: Left/right ear captain press the function key for 5 seconds to turn on.

③Pairing

Step 1: Take out the earbuds, and the left and right earbuds will automatically pair.

Step 2: Open the Bluetooth list of the smart device, search for "Neo-one PBX10" to pair and connect, After success, you will hear a prompt sound "Connected".

Touch operation

■ General mode



Voice Assistant: Five click right MFB

Volume Plus: Three click right MFB

Volume minus: Three click left MFB

■ Music playback mode



Pause/Play: Click left/right MFB

Previous: Double-click left MFB

Next: Double-click right MFB

■ Call mode



Answer: Double-click left/right MFB

Reject: Long press left/right MFB for 2 seconds

Hang up: Double-click left/right MFB

■ Game/ Music mode switch ANC mode switch



Press and hold left MFB for 3 seconds to switch game/ music mode

Press and hold right MFB for 3 seconds to switch ANC on and off Transparent mode

Included Items

- Charging case x 1
- Extra Silicon tips x 2
- User Manual x1
- Pair of Earbuds x 1
- Type-c Charging cable x 1



WARRANTY

The warranty covers your neoone product, including accessories against manufacturing defects (if any) for 12 months from the date of purchase.

Things that are not covered in the warranty

- Unauthorized tampering, modifications or repairs of the product.
- Physical damage of the product on the account of abuse, handling, storage, installation or testing including any use that is not in accordance with the product manual or documentation, or any other instruction provided along with the neoone product.

For further information on product replacement/refund related queries please refer to the terms and conditions mentioned in our online return policy section on www.neo-one.com.np